


Guide to using HyperTerminal to Download from your PAT Tester


On **XP machines** this can normally be found under Accessories, **Start > All Programs > Accessories > Communications > HyperTerminal**.

If you are running Windows Vista, you may not have HyperTerminal, in this case you can download it from the Internet or from the SimplyPats web site.

Run HyperTerminal



Click Yes when asked if you want to make HyperTerminal your default telnet program.



Type in a name for your new connection, for example, Test.


Click OK to continue.



Choose a COM port to use, and make sure your PAT Tester is plugged into that COM port.

If no COM ports are listed, then there are no free COM ports on your PC or there may be a hardware/software issue, please consult your IT Technician.

Press OK to continue.




Settings should be as follows:

Bits per second: **9600** (this is the baud rate, please set this to the **same rate as shown on your PAT**)

Data bits: **8**


Parity: **None**
Stop bits: **1**
Flow control: **None**

Click OK to continue.



You should now see the above screen.

On your PAT Tester, start the download as normal.




If your PAT has successfully downloaded, you should see the data, as shown above.

If required you can save this data as a .ht file, choose file > Save As

If the data displayed looks corrupt, you may need to try the download again using different settings outlined below.

Close down HyperTerminal and follow the steps above, but before you download set HyperTerminal to Capture Text.

Do this by clicking on **Transfer > Capture Text** in the file menu, you will now see the following window.



Choose a destination and name for your file and press start.

You can now set your PAT Tester to download.